


HOW TO ADJUST YOUR ROUTING PREFERENCES:

If your navigation system is not routing you in the way you expected or is taking unusual routes – be sure to check your navigation settings as this may be the issue. There are a few ways to do this:

1) While you are entering any destination:

- a. When you get to the final screen to 'GO' - press Route Options to ensure you have the preferred settings for that particular destination (your system may default to this setting on the next route)



2) Within the Navigation Settings:

- a. While in 'Navigation' Mode – Select 'Settings'
 - i. Within Settings – you can Avoid certain things on your Route such as Carpool lanes
 - ii. If you press 'More Settings' – you can change your:
 1. Preferred Route (Fastest or Eco Friendly)
 2. Check 'Traffic Preferences'

(note: If you have certain Onstar services- there may be traffic information coming in via Onstar that may also impact the route the system selects)

